

Hanhart and Tag Heuer Stopwatch Setup

1. Time Adjustment:

- a. Press **Mode** and **Start/Stop** buttons at the same time to clear the stopwatch
- b. Press **Mode** button twice to move display to time mode
- c. Press **Memory** button. The first hour digit will blink, adjust value using Split/Lap button. Press **Memory** button again to adjust next digit. Continue until the correct time is displayed
- d. Press **Mode** button to finish setting the current time.

2. Time of Day Setup:

- a. Press **Mode** and **Start/Stop** buttons at the same time to clear the stopwatch.
- b. Press **Start/Stop** button and **Split/Lap** buttons at the same time to enter time of day mode.
- c. The lower display will advance to the current time of day plus one minute
- d. Press **Start/Stop** button to synchronize to desired time of day.
- e. Press **Split/Lap** button and record time displayed on the LOWER display. The lower display time will remain displayed until the next time the **Split/Lap** button is pressed.
- f. In time of day mode, only the **Split/Lap** button functions until the stopwatch is cleared.

